
P.B. AMP. P.C. BOARD ND-5037
EQ. P.C. BOARD MU-5018
POWER SUPPLY P.C. BOARD MU-5017
REC. AMP. & OSC. P.C. BOARD MU-5016
LINE OUT
PHONE
LINE OUT
REC. LEVEL
TAPE SOURCE
MONITOR
TAPE SELECTOR
EQUALIZER
LEFT CH.
RIGHT CH.
POWER
GX-210D
SCHEMATIC DIAGRAM
NO.2-1 1480234A



GX-210D
SCHEMATIC DIAGRAM
NO.2-2 I480235A